



Poly Documentation

Copyright © 2024, Plantronics, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc
6001 America Center Drive

San Jose, CA 95002

USA

Contents

1. Poly Edge E Expansion Module Hardware Overview.	3
---	---

Poly Edge E Expansion Module Hardware Overview

The following figure displays the hardware features on the Poly Edge E Expansion Module. The table lists each numbered feature shown in the figure.

The following figures display the hardware features on the Poly Edge E Series expansion module. The tables list each numbered feature shown in the figures.

Poly Edge E Series expansion module hardware features - front




Table 1. Poly Edge E Series Expansion Module Hardware Descriptions - Front

Reference Number	Feature	Feature Description
1	Alignment tab	When connecting one EM, inserts into the alignment tab slot on the phone. When connecting a second EM on an E500 Series phone, inserts into the alignment tab slot on the first EM.
2	EM connector	Connects the EM to the phone. On an E500 Series phone, also connects a second EM to the first EM.
3	Line keys	Select a phone line, view calls on a line, or quickly call a favorite contact.

Reference Number	Feature	Feature Description
4	Line key LED indicators	<p>Indicates a line or busy lamp field contact's status. The following lists the LED Indicator behaviors shown on the expansion modules:</p> <ul style="list-style-type: none"> ● Solid Green—Indicates an active call in progress. ● Fast-Flashing Green—Indicates an incoming call. ● Flashing Green—Indicates the remote party placed the call on hold. ● Solid Red—Indicates the phone of a monitored busy lamp field contact is placing a call or is in a call. ● Flashing Red—Indicates a held call. ● Flashing Green and Red—Indicates the phone of a monitored busy lamp field contact is on an active call or is receiving an incoming call.
5	Color Display	Displays line numbers, monitored contacts, contacts' presence, and favorites.

Reference Number	Feature	Feature Description
6	Page keys	<p>Navigates between pages on the expansion module.</p> <ul style="list-style-type: none"> ● Solid Blue—Indicates the current page displayed. If not on the current page, the line appearance on the page is in an active state. ● Flashing Blue—Indicates that there is incoming call activity for a line or BLF on the page.

Poly Edge E Series expansion module hardware features - back




Table 2. Poly Edge E Series Expansion Module Hardware Descriptions - Back

Reference Number	Feature	Feature Description
1	USB-C port for E EM or headset connection	On an E500 Series phone, allows you to connect a second EM. If a second EM is not connected, you can use this port to connect a USB headset. You can also connect a USB headset to this port when an EM is connected to an E400 Series phone.
2	Stand or wall mount connection slots	Attach a desk stand or wall mount accessory to the EM
3	Alignment tab	When connecting one EM, inserts into the alignment tab slot on the phone. When connecting a second EM on an E500 Series phone, inserts into the alignment tab slot on the first EM.
4	EM connector	Connects the EM to the phone. On an E500 Series phone, also connects a second EM to the first EM.